

Proper Maintenance:

1. Remove pump from the pool after each use.
2. Disconnect and drain garden hose.
3. Remove, clean and replace pre-filter pad after each use. See right.



Protect Your Pump From Ice Damage

If the pump is going to be idle for a period of time, remove it from the pool and clean and dry it before storing. Do not let the pump freeze in wintertime. This may cause cracking or distortion that may destroy the pump and void the warranty.

Protect Your Pump From Debris

Your pump is equipped with a removable filter screen. This screen is to help prevent debris from becoming caught in the pump/impeller. If your pump becomes clogged, disconnect the pump from the power source, remove the filter screen and clean out the debris. Once the debris has been removed, the filter screen is easily reattached and you can continue pump operation.

Standard One-Year Limited Warranty Included

Please visit www.aquaproducts.com to register your product and review warranty details.



CAUTION: To avoid damaging pump never leave pump submerged in water that may freeze. Allowing ice to form inside the pump chamber will permanently damage the pump.



Cover Pump 350

**FOR ABOVE GROUND &
IN-GROUND POOL COVERS**



1 (877) 278-2797



CARE AND OPERATING INSTRUCTIONS

- This is a submersible, magnetically driven centrifugal pump that is designed specifically for the purpose of removing water off the top of swimming pool covers.
- This pump is equipped with a garden hose adapter. A standard garden hose should be attached to this adapter and be used to direct waste water away from the pool.
- This pump is equipped with a pre-filter pad designed to prevent debris from clogging the pump chamber and damaging the pump. This filter pad should be cleaned regularly.

Set Up:

1. Remove cover pump from box.
2. Unwind cord making sure that the plug stays dry at all times
3. Attach a garden hose to the adapter at the front of the pump.
4. Submerge the pump in the deepest area of water on your pool cover. Pump must be installed in a vertical position.
5. Direct the open end of the garden hose away from the pool.
6. Plug in the pump.


Pumps
up to
350
gallons
per hour



WARNING: For your protection always unplug the unit from its power source before installing or servicing. Should the unit appear not to be working **DO NOT REACH, REMOVE, or DISASSEMBLE UNIT** before you **DISCONNECT POWER**. This pump is intended to pump water only. It cannot be used to pump oils, solvents or gasoline.

1. Always use a properly grounded outlet. (See figure 1.)
2. The National Electrical Code requires that a Grounded Fault Circuit Interrupter (GFCI) be installed in the branch circuit supplying the outlet that this pump is plugged into.
3. Do not immerse plug into water.
4. **DO NOT REACH INTO WATER TO REMOVE PLUG, TURN OFF CIRCUIT FIRST.**
5. A drip loop should be provided. The drip loop is a loop in the cord below the level of the receptacle that prevents water from traveling along the cord. (See figure 2.)
6. **NEVER REMOVE THE GROUND PIN FROM PLUG.** (See figure 3.)

figure 1.



Grounded
Outlet Box

figure 2.




figure 3.

